

10" ELECTRIC DRUM BRAKE SERVICE PARTS



5



339102
Magnet clip – 10" electric

6



339110
Magnet spring

7



339114
10" Electric brake, Magnet lever
left hand

7



339115
10" Electric brake, Magnet lever
right hand

8



339130
10" Electric brake, Shoe retractor
spring (Top)

9



339127
10" Electric brake, Shoe retainer
cup & spring

10



339128
Electric brake, Adjuster spring
(Bottom)

11



339129
10" Electric brake, Park lever
return spring

12



390021
10" Electric brake, Mounting nut
7/16" UNF Zinc Plated

13



339103
10" Electric brake, Adjuster plug

14



190054
10" Electric brake, Mounting
washer 7/16" external shake
proof

Helpful Hint:

Consider the benefits by replacing an entire backing plate rather than replacing a few parts. It may cost more however it gives peace of mind for all components & in some cases quicker to do.